






















































PROVISION ISR[®] Junction boxes









































Now you can see!

Model	Junction boxes		Installation				
Dome  DI-VF	Wall A  PR-WB-A	OR IP66  PR-JB14IP66 IP64  PR-JB14IP64	Wall B  PR-WB14 <small>optional</small>  PR-B10EX	Ceiling  PR-CB14 <small>optional</small>  PR-B10EX	Pole  PR-B50PB <small>optional</small>  PR-WB14	Corner  PR-B50ECB <small>optional</small>  PR-WB14	
Dome  DI-FIX	Wall A  PR-WB-A	OR IP66  PR-JB12IP66 IP64  PR-JB12IP64	Wall B  PR-WB12 <small>optional</small>  PR-B10EX	Ceiling  PR-CB12 <small>optional</small>  PR-B10EX	Pole  PR-B50PB <small>optional</small>  PR-WB12	Corner  PR-B50ECB <small>optional</small>  PR-WB12	
Dome  DAI-VF	IP66  PR-JB14IP66	* + Wall  PR-WB14 <small>optional</small>  PR-B10EX	Ceiling  PR-CB14 <small>optional</small>  PR-B10EX	Pole  PR-B50PB <small>optional</small>  PR-WB14	Corner  PR-B50ECB <small>optional</small>  PR-WB14	OR Ceiling  PR-ICB23	
Dome  DAI-FIX	Wall A  PR-WB-A	* + IP66  PR-JB12IP66	Wall  PR-WB12 <small>optional</small>  PR-B10EX	Ceiling  PR-CB12 <small>optional</small>  PR-B10EX	Pole  PR-B50PB <small>optional</small>  PR-WB12	Corner  PR-B50ECB <small>optional</small>  PR-WB12	OR Ceiling  PR-ICB21
Dome  FEI	IP66  PR-B50JB	OR Wall  PR-WB50 <small>optional</small>  PR-B10EX	Ceiling  PR-CB50 <small>optional</small>  PR-B10EX				

*** For DAI Installations, please remove the junctions box cover and connect the camera directly to the junction box**

PROVISION ISR[®] Junction boxes

Now you can see!

Model	Junction boxes		Installation							
Bullet  I6	IP66  PR-JB14IP66	IP64  PR-JB14IP64	Wall  PR-WB14	optional  PR-B10EX	Ceiling  PR-CB14	optional  PR-B10EX	Pole  PR-B50PB	optional  PR-CB14	Corner  PR-B50ECB	optional  PR-CB14
Bullet  I4	IP66  PR-JB12IP66	IP64  PR-JB12IP64	Wall  PR-WB12	optional  PR-B10EX	Ceiling  PR-CB12	optional  PR-B10EX	Pole  PR-B50PB	optional  PR-CB12	Corner  PR-B50ECB	optional  PR-CB12
Bullet  I2	IP66  PR-JB12IP66	IP64  PR-JB12IP64	Wall  PR-WB12	optional  PR-B10EX	Ceiling  PR-CB12	optional  PR-B10EX	Pole  PR-B50PB	optional  PR-CB12	Corner  PR-B50ECB	optional  PR-CB12
Dome  DMA	Wall A  PR-WB-A	OR	 PR-B10BJB	Wall B  PR-WB12	optional  PR-B10EX	Ceiling  PR-CB12	optional  PR-B10EX			