



In-ceiling Mount

SHP-1730FPW




Package




Top Cover




Screw Cap (4EA)



Installation Guide Sticker




Safety Wire



Safety Bracket





PT01-006119B

Installation Precautions




• Be sure to secure the Safety Wire to avoid a product fall.


Installation




5




6




7




8




9




10




11



12



13



If the 3 fixing screws at the top of the housing are not tightened securely, the camera may be detached from mount during operation.